

**PROPERTIES**
**USE AND MAINTANCE**

|                        |   |   |   |
|------------------------|---|---|---|
| Copper Line            |    | <ul style="list-style-type: none"> <li>● 3 Ply Copper-Alum- Steel</li> <li>● 2 mm - 2,6 mm Thickness</li> <li>● Brass \ S.steel Handles</li> <li>● AG2 Alloy Rivets</li> <li>● Don't Require Tinning</li> <li>● Unsuitable For Microwave</li> <li>● Unsuitable For Induction</li> </ul> | <ul style="list-style-type: none"> <li>● Don't Wash in the Dishwasher</li> <li>● Wash and Dry By Hand Only.</li> <li>● The Handles Are Metal and Can Get Hot on Cooktop</li> <li>● Use Oven Gloves or Kitchen Towel</li> <li>● The Copper Outer Layer May Get Dark Over Time, it is Recommended To Use a Special Copper Cleaner to Keep it Shiny</li> <li>● Don't Leave Your Pan on Stove For a Long Time Without Food</li> </ul>   |
| Steel Line             |    | <ul style="list-style-type: none"> <li>● 3 Ply Steel-Alum- Steel</li> <li>● 2 mm - 2,6 mm Thickness</li> <li>● S.steel Handles</li> <li>● AG2 Alloy Rivets</li> <li>● Suitable For Induction</li> <li>● Unsuitable For Microwave</li> </ul>   | <ul style="list-style-type: none"> <li>● Dishwasher-Safe</li> <li>● The Handles Are Metal and Can Get Hot on Cooktop</li> <li>● Use Oven Gloves or Kitchen Towel</li> <li>● Don't Leave Your Pan on Stove For a Long Time Without Food</li> </ul>   |
| Silver Star Line       |    | <ul style="list-style-type: none"> <li>● 2 Ply Steel-Alum</li> <li>● 2,80 mm Thickness</li> <li>● S.steel Handles</li> <li>● AG2 Alloy Rivets</li> <li>● Suitable For Induction</li> <li>● Unsuitable For Microwave</li> <li>● Non-Stick Coating</li> </ul>                             | <ul style="list-style-type: none"> <li>● Before First Use, Wash and Dry The Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> <li>● Pour a Thin Layer of Liquid Fat, Wait a Moment and Wipe</li> <li>● Wash and Dry By Hand Only.</li> <li>● The Handles are Metal and Can Get Hot on Cooktop, Use Oven Gloves or Kitchen Towel</li> <li>● Don't Leave Your Pan on Stove For a Long Time Without Food</li> <li>● Don't Use Metal Spoons or Cutting Tools</li> <li>● Use Plastic and Wooden Utentils.</li> <li>● Don't Expose Your Pan to Sudden Temperature Changes</li> <li>● Don't Wash in the Dishwasher</li> </ul> |
| Non-Stick Line         |   | <ul style="list-style-type: none"> <li>● Pure Aluminium</li> <li>● 3,5 mm Thickness</li> <li>● AG2 Alloy Rivets</li> <li>● Non-Stick Coating</li> <li>● Pfoa Free</li> <li>● Unsuitable For Induction</li> <li>● Unsuitable For Microwave</li> </ul>                                    | <ul style="list-style-type: none"> <li>● Before First Use,Wash and Dry the Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> <li>● Pour a Thin Layer of Liquid Fat,Wait a Moment and Wipe</li> <li>● Don't Use Metal Spoons or Cutting Tools</li> <li>● Use Plastic and Wooden Utentils.</li> <li>● Don't Leave Your Pan on Stove For a Long Time Without Food</li> <li>● Don't Expose Your Pan To Sudden Tempature Changes</li> <li>● Be Careful Not To Burn Fat in An Empty Pan</li> </ul>   |
| Anodized Line          |  | <ul style="list-style-type: none"> <li>● Anodized Aluminium</li> <li>● Suitable For Food Contact</li> <li>● Not Suitable For Use in Microwave and Induction Cookers</li> </ul>  | <ul style="list-style-type: none"> <li>● Before First Use,Wash and Dry the Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> <li>● The Handles Are Metal and Can Get Hot on Cooktop</li> <li>● Use Oven Gloves or Kitchen Towel</li> </ul>   |
| Cast Iron & Fajita Set |  | <ul style="list-style-type: none"> <li>● Cast Iron Body</li> <li>● Non-Stick Coating</li> </ul>   | <ul style="list-style-type: none"> <li>● Before First Use,Wash and Dry the Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> <li>● Pour a Thin Layer of Liquid Fat,Wait a Moment and Wipe</li> <li>● Don't Use Metal Spoons or Cutting Tools</li> <li>● Use Plastic and Wooden Utentils.</li> <li>● Don't Leave Your Pan on Stove For a Long Time Without Food</li> <li>● Don't Expose Your Pan To Sudden Tempature Changes</li> </ul>   |
| Stainless Steel        |  | <ul style="list-style-type: none"> <li>● Stainless Steel Body</li> <li>● Mirror Polished</li> </ul>   | <ul style="list-style-type: none"> <li>● Before First Use,Wash and Dry the Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> <li>● Don't Use Chemicals</li> <li>● Don't Use Metal Spoons or Cutting Tools</li> </ul>   |
| Wire Baskets           |  | <ul style="list-style-type: none"> <li>● Metal Wire Body</li> <li>● Black Epoxy Polyester</li> <li>● Handcrafted</li> </ul>   | <ul style="list-style-type: none"> <li>● Don't Wash in the Dishwasher</li> <li>● Don't Use Chemicals</li> <li>● Before First Use,Wash and Dry the Product With Warm Detergent Water and Dry it Wipping With a Clean Kitchen Cloth</li> </ul>  |
| Beechwood              |  | <ul style="list-style-type: none"> <li>● Beech Plywood Body</li> <li>● Mineral Oieled Surface</li> </ul>  | <ul style="list-style-type: none"> <li>● Before First Use,Wash and Dry the Product</li> <li>● Don't Use Chemicals To Clean</li> <li>● Don't Put in the Microwave or Oven</li> <li>● Don't Wash in the Dishwasher</li> <li>● To Prevent Cracks on the Wooden Surface,You Sholuld Lubricate With Natural Oil Periodically.</li> <li>● Do Not Leave It in the Oven and on Stove in Order To Avoid Drying or Burning.</li> <li>● These Precautions Will Expand the Life of Your Product.</li> </ul>   |